

WEST SYSTEM PRODUCT SELECTION CHART

This Product/Application Overview shows how bonding, fairing and coating applications are related to combinations of specific products.

Step 1

Start with 105 resin, the basic ingredient of all WEST SYSTEM epoxy compounds.

Step 2

Mix with one of four WEST SYSTEM hardeners. Select a hardener for its intended use and for the cure speed best suited for your job in the temperature range in which you are working.

Step 3

Use correct 301 or 303 pumps for convenient and accurate metering.

Step 4

Add one of eight WEST SYSTEM fillers to thicken the mixture as needed. Select a filler for its handling characteristics or cured physical properties. Or, add one of six WEST SYSTEM additives to provide specific coating properties.

